

Labtex

AATCC M6 WASHING MACHINE MODEL: LBT-M6T



OPERATION INSTRUCTION

[Version 2.3x]

OPERATION INSTRUCTION

INDEX

I.	IMPORTANT SAFETY INSTRUCTIONS	2
II.	INTRODUCTION	
1.	Definition of Use	4
III.	PARTS DESCRIPTION	
1.	Control Panel	5
A.	Water Level Control Knob	6
B.	Program Selector Knob.....	6
C.	Capacitive LCD Touch Panel.....	7
	Table 1: Pre-set Program List	9
2.	Precision Water Temperature Control Device	10
3.	Accessories	10
IV.	BEFORE START	
1.	Dimensions	11
2.	Specifications	12
V.	INSTALLATION	13
VI.	ELECTRICAL REQUIREMENT	14
VII.	OPERATION	15
VIII.	MAINTENANCE	16
IX.	TRANSPORT/HANDLING	18
X.	NOTE	19

OPERATION INSTRUCTION

I. IMPORTANT SAFETY INSTRUCTIONS

BEFORE USING THIS INSTRUMENT, READ ALL INSTRUCTIONS AND CAUTIONARY MARKINGS IN THIS MANUAL

Throughout this manual and on machine decals, you will find precautionary statements (“Warning” and “Important”) followed by specific instructions. These precautions are intended for the personal safety of the operator, user, servicer, and those maintaining the machine.



Indicates a hazardous situation that, if not avoided, could cause severe personal injury or death.



Inform the reader of specific procedures where minor machine damage will occur if the procedure is not followed.



Indicates a hazardous situation that, if not avoided, may cause minor or moderate personal injury or property damages.

OPERATION INSTRUCTION



Use the washing machine only for its intended purpose, washing textiles, clothes or fabrics. Any others materials are prohibited.

When using an electrical appliance, basic precautions should always be followed, including the following:



For your safety and to reduce the fire or an explosion, do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any appliance.



The circuit in the instrument is high voltage, please do not open the instrument for non-maintenance personnel.

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY:

1. Use only as described in this Instruction Manual. Do not carry out any maintenance other than that shown in this manual.
2. Do not handle any part of the plug or machine with wet hands.
3. Do not use with a damaged cord or plug. If the supply cord is damaged it must be replaced by a qualified persons in order to avoid a hazard.
4. Keep this instruction manual by the specialist in a safe place.
5. If the machine is not working as it should, has received a sharp blow, has been dropped, damaged, left outdoors, or dropped into water, do not use and contact your supplier / distributor.
6. Contact the supplier / distributor when service or repair is required. Do not disassemble the machine as incorrect reassembly may result in an electric shock or fire.
7. Do not stretch the cord or place the cord under strain. Keep the cord away from heated surfaces. Do not close a door on the cord, or pull the cord around sharp edges or corners. Arrange the cord away from traffic areas and where it will not be stepped on or tripped over. Do not run over the cord.
8. When handling the instrument, do not use violence to avoid damage to the instrument.
9. The instrument is used normal environment, use an elevation of less than 2,000 meters.

READ AND SAVE THESE INSTRUCTIONS

OPERATION INSTRUCTION

II. INTRODUCTION

1. Definition of Use

The Labtex Washing Machine LBT-M6 is exclusively destined to wash and spin machine washable laundry which is mainly for laboratory and meet the parameters which listed on AATCC LP1 Table I, IIC, IID, IIIA and IIIB.

METHOD	DESCRIPTION
AATCC 88B	Seam Smoothness in Fabrics after Home Laundering
AATCC 88C	Crease Retention in Fabrics after Home Laundering
AATCC 124	Smoothness Appearance of Fabrics after Home Laundering
AATCC 130	Soil Release: Oily Stain Release Method
AATCC 135	Dimensional Changes of Fabrics after Home Laundering
AATCC 142	Appearance of Flocked Fabric after Repeated Home Laundering and/or Coin-Op Drycleaning
AATCC 143	Appearance of Apparel and Other Textile End Products After Home Laundering
AATCC 150	Dimensional Changes of Garments after Home Laundering
AATCC 172	Colorfastness to Powdered Non-Chlorine Bleach in Home Laundering
AATCC 179	Skew Change in Fabrics After Home Laundering

This manual are used to helps the operator to use the washer correctly.


Labtex

AATCC-M6T Washing Machine **LBT-M6T**

OPERATION INSTRUCTION

III. PARTS DESCRIPTION

1. Control Panel



ITEM	DESCRIPTION
Z	Washer Status Indication Lamps When Red Lamp Lit: Washer stopped or Pause When Green Lamp Lit: Washer operating
A	Water Level Control Knob
B	Program Selector Knob
C	Capacitive LCD Touch Panel

OPERATION INSTRUCTION

A. Water Level Control Knob




Choose From 6 Different Load Sizes

Liter	30	44	57	68	72	83
Gallon	8	11.5	15	18	19	22

**Please refer to AATCC Standard requirements*



B. Program Selector Knob



- Rotate the knob to select different programs
- Press the knob to enter the program.

OPERATION INSTRUCTION

C. Capacitive LCD Touch Panel

	Program selection interface : Enter the program by touching the corresponding program for one second or use the program selection knob to operate.
	Taking the program 'Table I Normal' as an example : After entering the program, the operation interface provides configuration options for fixed water level, temperature, and cycle count.
	Enter the water temperature setting: Set the temperature by entering the desired value and pressing the "OK" button to save the settings.

OPERATION INSTRUCTION

Water Level (L)

(1~90)

1	2	3
4	5	6
7	8	9
.	0	<X>

OK

CANCEL

Enter the water level setting:

Set the temperature by entering the desired value, and press the "OK" button to save the settings.

Cycles

(1~100)

1	2	3
4	5	6
7	8	9
.	0	<X>

OK

CANCEL

Enter the cycles setting:

Set the cycles the desired value (or using the Water Level Control Knob), and press the "OK" button to save the settings.

+

00

-

+

01

-

:

36

-

OK

CANCEL

2025 January

Su	Mo	Tu	We	Th	Fr	Sa
29	30	31	1	2	3	4
5	6	7	8	9	10	11
12	13	14	15	16	17	18
19	20	21	22	23	24	25
26	27	28	29	30	31	1
2	3	4	5	6	7	8

Enter the delay start setting:

You can run the machine by setting a future time.

Labtex

AATCC-M6T Washing Machine

LBT-M6T

OPERATION INSTRUCTION

Table 1: Preset Program

Rotate the knob clockwise and counterclockwise to select a program, or directly click the touch screen to select a program.



Labtex

中文
En



2025-01-16 00: 00: 04

1

L001 Table I Normal

AATCC LP1-2021 88B 88C 124 135 143 150-2018t 19gal 86spm 16min 660rpm 5min

2

L002 Table I Delicate

AATCC LP1-2021 88B 88C 124 135 143 150-2018t 19gal 27spm 8.5min 500rpm 5min

3

L003 Table I Permanent Press

AATCC LP1-2021 88B 88C 124 135 143 150-2018t 19gal 86spm 12min 500rpm 5min

4

L004 Table IIC Noemal (2011-2012)

AATCC LP1-2021 19gal 86spm 16min 660rpm 5min

5

L005 Table IIC Delicate (2011-2012)

AATCC LP1-2021 19gal 27spm 8.5min 500rpm 5min

Labtex

中文
En

2025-01-16 00: 00: 04

6

L006 Table IIC Permanent Press (2011-2012)
AATCC LP1-2021 19gal 86spm 12min 500rpm 5min

7

L007 Table IID Normal (2013-2017)
AATCC LP1-2021 19gal 86spm 16min 660rpm 5min

8

L008 Table IID Delicate (2013-2017)
AATCC LP1-2021 19gal 27spm 8.5min 500rpm 5min

9

L009 Table IIIA Noemal (2013-2017) HE
AATCC LP1-2021 18gal 60spm 11min 770rpm 6min

10

L010 Table IIIA Delicate (2013-2017) HE
AATCC LP1-2021 15gal 75spm 9min 500rpm 6min

Labtex

中文
En

2025-01-16 00: 00: 04

11

L011 Table IIIB Normal (2018) HE
AATCC LP1-2021 18gal 60spm 14min 660rpm 6min

12

L012 Table IIIB Delicate (2018) HE
AATCC LP1-2021 18gal 70spm 8min 660rpm 3min

13

L013 Table IIA Noemal (2000-2008)
AATCC LP1-2021 88B 88C 124 135 143 150-2018t 19gal 179spm 12min 645rpm 6min

14

L014 Table IIA Delicate (2000-2008)
AATCC LP1-2021 88B 88C 124 135 143 150-2018t 19gal 119spm 8min 430rpm 6min


15

L015 Table IIA Permanent Press (2000-2008)
AATCC LP1-2021 88B 88C 124 135 143 150-2018t 18gal 179spm 10min 430rpm 4min

Labtex	中文 En	 2025-01-16 00: 00: 04
16	L016 Table IIB Normal (2009-2010) AATCC LP1-2021 88B 88C 124 135 143 150-2018t 18gal 179spm 12min 645rpm 6min	
17	L017 Table IIB Delicate (2009-2010) AATCC LP1-2021 88B 88C 124 135 143 150-2018t 18gal 119spm 6min 430rpm 3min	
18	L018 Table IIB Permanent Press (2009-2010) AATCC LP1-2021 88B 88C 124 135 143 150-2018t 18gal 179spm 9min 430rpm 4min	
19	L019 RINSE&SPIN	
20	L020 DRAIN&SPIN	

OPERATION INSTRUCTION


2. Precision Water Temperature Control Device



ITEM	DESCRIPTION
i	Tap water connection to washtub
ii	Mixed water connection to washtub
iii	Cold water connection
iv	Hot water connection
v	Mixed water outlet

3. Accessories


- i. Fill Hose
- ii. Hose adaptor
- iii. Rubber Foot
- iv. Filter Screen



OPERATION INSTRUCTION

IV. BEFORE START


1. Dimensions:



11

Before install the washer,
the basic tools you may need
are:

- i. Wrench
- ii. Screwdriver
- iii. Pliers
- iv. Level



OPERATION INSTRUCTION


2. Specifications:

Model	LBT-M6T
Meet Standard	AATCC 88B, 88C, 124, 130, 135, 142, 143, 150, 172, 179 ISO 6330:2021(E)Table C.1
Washing Cycles	Normal, Permanent Press, Delicate for AATCC Drain & Spin, Rinse & Spin Customized
Pre-Programmed Cycle	AATCC LP1-2021 Table I, IIC, IID, IIIA, IIIB
Water Level (gal)	22 +/-1 or Customized
Agitation Speed (spm)	60 – 179 +/- 2 or Customized
Washing Time (min)	8 – 9999 or Customized
Final Spin Speed (rpm)	430 – 770 +/- 15 or Customized
Final Spin Time (min)	5 or Customized
Durability Test	Maximum 9999 times or 9999 minutes or Customized
Water Input	Hot / Cold
Mixed Water Control	25 ~ 60+/-1°C (wash) Tap Water (Rinse)
Washing Load	10.5KG
Wash Tub	Stainless Steel
Agitator	Plastic Flex Vane Post
Sound power level	Maximum L _{WA} 79 dB
Power	110-240V~; 50-50Hz; 1000 W; IPX4
Packing Size (mm)	820*810*1330
Gross Weight (Kg)	104
Packing Weight (Kg)	133
Stroke Length	Up to 220°

OPERATION INSTRUCTION

V. INSTALLATION

1. Remove the shipping case and take out machine from packing carton.
2. Wipe out inside of washtub
3. Connect fill hoses, make sure both COLD and HOT Faucet had been connect to Temperature Control Device.
4. Connect drain hose to drain receptacle
5. Position and level the washer.
6. Connect the washer to Electrical Power



13

!
IMPORTANT

Thread hose couplings onto valve connections finger tight, then turn 1/4 turn with pliers. DO NOT cross thread or overtighten couplings.

OPERATION INSTRUCTION

VI. ELECTRICAL REQUIREMENT

220V/50Hz/1KW Or 120V/60Hz/1.5KW

 WARNING	To reduce the risk of fire, electrical shock, serious injury or death, all wiring and protective earth/ground connections MUST conform with the latest edition of the National Electrical Code, ANSI/NFPA No. 70, and such local regulations as might apply. It is the customer's responsibility to have the wiring, fuses and circuit breakers installed by a qualified electrician to make sure adequate electrical power is available to the washer.
---	---

When plugging inn the Labtex M6T:

- DO NOT overload circuits.
- DO NOT use an adapter.
- DO NOT use an extension cord.
- The machine is designed to be operated on a separate branch, polarized three-wire, effectively grounded (earthed) 110-240 V~, 50-60 Hz, AC (alternating current), circuit protected by a **15 ampere fuse**, equivalent fusetrone or circuit breaker.
- The three-prong grounding plug on the power cord should be plugged directly into a polarized three-slot effectively grounded receptacle rated 220 Volts or 120 Volts AC (alternating current) 15 Amps.
- Do not modify the plug provided with the washer – if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

OPERATION INSTRUCTION

VII. OPERATION

Follow below example:

1. Power on Washer.
2. Select a washing cycle by Capacitive LCD Touch Panel or turning the Program Selector Knob (Refer to Table I and AATCC test method)
3. Set the required water level (Refer to AATCC test method)
4. Set the required water temperature
5. Press "START" button to fill water into the washtub.
6. When the water level (filling stopped) and temperature reach the setting, press on the "Start" button again to pause the washing cycle, open the lid and add the **detergent**, **test specimen** and the **ballasts** into the washer.
7. Close the lid and press on the start button to run the washing cycle.
8. The washer will run and finish automatically. The "Red" indication lamp will be "Lit" after washing cycle completed.



OPERATION INSTRUCTION

VIII. MAINTENANCE

Cold Weather Care

If the washer is delivered on a cold day (below freezing), or is stored in an unheated room or area during the cold months, do not attempt to operate it until the washer has had a chance to warm up.

Care of Your Washer

1. Use only a damp or sudsy cloth for cleaning the control panel.
2. Wipe the washer cabinet products are spilled on the cabinet, wipe immediately.
3. Do not use scouring pads or abrasive cleaners on any part of the washer.
4. The washtub will need no particular care though it may need rinsing or wiping after an unusual load has been washed.
5. Leave the lid open to allow the inside of the washers to dry out after use. This helps prevent musty odors from developing.

 IMPORTANT	Hoses and other natural rubber parts deteriorate after extended use. Hoses may develop cracks, blisters or material wear from the temperature and constant high pressure they are subjected to.
	All hoses should be checked on a monthly basis for any visible signs of deterioration. Any hose showing the signs of deterioration listed above should be replaced immediately. All hoses should be replaced every five years.

Vacations and Extended Non-Use

 IMPORTANT	To avoid possible property damage due to flooding, turn off the water supply to the washer whenever there will be an extended period of non use.
---	--

OPERATION INSTRUCTION

Filter Screens

Check the filter screen in the fill hoses for debris or damage annually. Clean or replace them if necessary.

If the washer is filling with water slower than normal, check the filter screens. Clean or replace them if necessary.

Motor Overload Protector

This internal overload protector will also stop the motor automatically in the event of an overload. The overload protector will reset itself in two or three minutes and the motor will restart automatically. If the overload protector stops the motor again, remove the washer from use and contact our agent / distributor.

Before You Call for Service

If the washer:

Won't Fill	Won't Start	Won't Agitate	Won't Spin	Possible Reason – Do This to Correct
●	●	●	●	Be sure power cord is plugged all the way into the electrical outlet.
	●	●	●	Close the lid
●	●	●	●	Check the house
	●	●	●	Has the motor overload protector cycled?
●				Turn on the hot and cold water faucets.
●	●	●	●	Push "START" button to start the washer.
●				Was the last spin completed?
●				Clean the screens in the water mixing valve and the filter screens in the fill hoses.
●				Water is siphoned from the washer during the cycle. Refer to Installation section
●	●			Are controls properly set?
		●	●	Broken drive belt. Call the service person.

OPERATION INSTRUCTION

IX. TRANSPORT/HANDLING

 WARNING	Excessive Weight Hazard Use two or more people to move and install washer. Failure to do so can result in back or other injury.
---	---

Never lift the appliance by the worktop when transporting

1. Pull out the mains plug
2. Turn off the tap
3. Check that machine door and detergent dispenser are properly closed
4. Disconnect the inlet and drain hoses
5. Eliminate all water from the hoses and from the appliance
6. Fit the transport bolts (obligatory)

Manufacturers:	LABTEX TECHNOLOGY CO., LIMITED
Address:	Flat B, 7/F., Mai Gar Ind'l Bldg., 146 Wai Yip Street, Kwun Tong, Kowloon, Hong Kong.
Website:	www.lab-wash.com
Email:	info@lab-wash.com

